



Make Every Moment Count.®

GETTING STARTED WITH YOUR TIME TIMER® PLUS

2023 & BEYOND EDITIONS

Congratulations on the purchase of your new Time Timer® PLUS. We hope that it helps you make every moment count!



1

INSTALL TWO AA BATTERIES

The battery cover is located on the back of your Time Timer® PLUS. Simply open battery cover down to insert batteries into compartment.



2

CHOOSE YOUR SOUND PREFERENCE

The timer itself is quiet—no distracting ticking sound—but you can choose the volume and whether or not to have an alert sound when time is complete. Simply use the volume-control dial on the back of the timer to control audio alerts.



3

SET YOUR TIMER

Turn the center knob on the front of the timer counter-clockwise until you reach your chosen amount of time. As long as the pause/play button is flush with product, your new timer will begin to count down, and a quick glance will reveal the time left thanks to the brightly colored disk and large, easy-to-read numbers.



4

PAUSE FEATURE

If you would like to pause your timer, simply push the pause/play button on the front of the timer to engage the pause feature. The orange ring around the pause button will be visible and the countdown will pause until the button is pushed again and countdown resumes.



BATTERY RECOMMENDATIONS

We recommend using high-quality, name-brand alkaline batteries to ensure accurate timing. You may use rechargeable batteries with Time Timer®, but they may deplete more quickly than traditional batteries. If you do not plan to use your Time Timer® for an extended period of time (several weeks or more), please remove the batteries to avoid corrosion.

PRODUCT CARE

Our timers are manufactured to be as durable as possible, but like many clocks and timers, they have a quartz crystal inside. This mechanism makes our products quiet, accurate and easy to use, but it also makes them sensitive to being dropped or thrown. Please use with care.