



Make Every Moment Count.®

## GETTING STARTED WITH YOUR TIME TIMER® VISUAL SCHEDULER


Congratulations on the purchase of your new Time Timer® Visual Scheduler. We hope that it helps you make every moment count!



1

### INSTALL 2 AA BATTERIES


The battery compartment is located on the back of the Time Timer® Original Medium. Simply pull down from the top of the battery compartment to insert batteries.



2

### CHOOSE YOUR SOUND PREFERENCE

The timer itself is quiet—no distracting ticking sound—but you can choose whether or not to have an alert sound when time is complete. Simply use the red on/off switch on the back of the timer to control audio alerts.



3

### PLACE TIMER IN ACCESSORY


Slide timer into slot on back of Visual Scheduler accessory and gently push forward to lock in place. (Fits all Time Timer Original Medium Timers)



4

### PLACE CLIPS AND ACTIVITY CARDS

Gently slide the clips into the inner opening until they snap in place. Clips should slide freely around lip to indicate time blocks. Choose activities from the provided activity cards, or use your own. Slide the activity cards under the clips.



5

### WRITE ON DRY ERASE BOARD


The dry erase surface and included dry erase marker allow endless possibilities for your visual schedule. Dry erase marker, clips, and activity cards can be stored in caddy on back when not in use.



6

### SET YOUR TIMER

Use the center knob to turn the red disk counter-clockwise until you reach your chosen amount of time. Immediately, your new timer will begin to countdown, and a quick glance will reveal the time left thanks to the brightly colored disk.



### BATTERY RECOMMENDATIONS

We recommend using high-quality, name-brand alkaline batteries to ensure accurate timing. You may use rechargeable batteries with Time Timer®, but they may deplete more quickly than traditional batteries. If you do not plan to use your Time Timer® for an extended period of time (several weeks or more), please remove the batteries to avoid corrosion.

### PRODUCT CARE

Our timers are manufactured to be as durable as possible, but like many clocks and timers, they have a quartz crystal inside. This mechanism makes our products quiet, accurate and easy to use, but it also makes them sensitive to being dropped or thrown. Please use with care.

QUESTIONS? WE'RE HERE TO HELP: [INFO@ROBO-TOYS.COM](mailto:INFO@ROBO-TOYS.COM)